

Loading Instructions for the Label Dispenser

1. Place the reel of labels in the dispenser.
2. Take the end of the reel and feed it through the top rollers:
 - Under the large roller
 - Up and over the first small roller
 - Then down again between it and the spring roller



3. Pull the end of the reel. As the labels pass through the rollers, they will separate from the backing paper and "sit" on the spring roller ready for handling.

NOTE:

If your reel size is near the dispenser maximum, unwind approximately 150mm (6 inches) of labels first and feed the end through the rollers. Then place the reel in the dispenser.

Contact our customer service team:

01299 250 981

sales@labelsonline.co.uk

Scan the QR code to chat with us directly

